

Monitor **MC20**


ELECTRIC FENCE VOLTAGE MONITORING 24/7

Monitor important electric fence values in the fencee Cloud app and get real-time warning alerts.


	LTE Monitor MC20
POWER SUPPLY	3 V
BATTERY	2 × 1,5 V Alkaline LR14 8000 mAh
INTEGRATED ANTENNAS	✓
LED INDICATION	✓
SOUND SIGNAL	✓
MAGNETIC SWITCH MODE	✓
LTE	✓
GPS	✓
NB-IoT	✓
BLUETOOTH	2,4 GHz
TRANSMITTING POWER LTE	+22 dBm
TRANSMITTING POWER BLUETOOTH	+6 dBm
DIMENSION	78 × 144 × 42 mm
WEIGHT	300 g



UNLIMITED CONTROL



LED INDICATION




LTE TECHNOLOGY



Cloud CONNECTION




How does it work?




1 The LTE monitor recognizes a drop in the fence voltage and sends information to the fencee Cloud.



2 The fencee Cloud sends an alarm within a few seconds.



3 You can switch off the power supply on fence conveniently via the fencee Cloud application and eliminate a problem.



4 Once the problem is eliminated, you can switch on the energizer using the app and check the fence voltage on your mobile phone.



REAL-TIME
WARNING ALERTS



ONLINE
MONITORING



SAVES TIME
AND COSTS



OPERATION
WITHOUT FEES



Control your device
from anywhere on your
mobile phone with
fencee Cloud app

